

## INSTALLATION INSTRUCTIONS

Any Stone Forest vanity or console being installed on metal sink legs requires *additional wall support* where the sink attaches to the wall.

This bracket is provided with your Stone Forest vanity/console and should be adequately attached to the wall with the proper anchors and bolts based on the wall material and construction.

The leg systems alone are not designed to completely support the sinks.



Note the aluminum angle bolted to the wall supporting the granite slab.

To secure the legs to the underside of the sink, simply use a dab of silicone adhesive, provided in the hardware kit. As an alternative, you may drill a 3/16" diameter hole approx. 3/8" deep in the underside of the stone slab and align with the threaded studs, which can be inserted into the top of each leg